SCHEDULE 2 UNIQUE CONDITIONS

5K Miles (4 months)
Replace engine oil
Replace engine oil filter
Rotate tires
Lubricate all locks and hinges
Inspect:
- Engine coolant level
- Function of all lights
- Brake fluid level
- Tire inflation pressure and tire wear
- Power steering fluid level
- Washer fluid level

10K Miles (8 months)
Replace engine oil
Replace engine oil filter
Rotate tires
Lubricate all locks and hinges
Inspect:
- Engine coolant level
- Function of all lights
- Brake fluid level
- Tire inflation pressure and tire wear
- Power steering fluid level
- Washer fluid level

15K Miles (12 months)
Replace engine oil
Replace engine oil filter
Rotate tires
Clean air filter
Lubricate all locks and hinges
Inspect:
- Engine coolant level
- Function of all lights
- Brake fluid level
- Disc brakes
- Tire inflation pressure and tire wear
- Power steering fluid level
- Washer fluid level

20K Miles (16 months)
Replace engine oil
Replace engine oil filter
Rotate tires
Lubricate all locks and hinges
Inspect:
- Engine coolant level
- Function of all lights
- Brake fluid level
- Tire inflation pressure and tire wear
- Power steering fluid level
- Washer fluid level

25K Miles (20 months)
Replace engine oil
Replace engine oil filter
Rotate tires
Lubricate all locks and hinges
Inspect:
- Engine coolant level
- Function of all lights
- Brake fluid level
- (Continued)
- Tire inflation pressure and tire wear
- Power steering fluid level
- Washer fluid level

30K Miles (24 months)
Replace engine oil
Replace engine oil filter
Replace manual transmission oil
Replace rear differential oil
Rotate tires
Clean air filter
Tighten bolts and nuts on chassis and body
Lubricate all locks and hinges
Inspect:
- Engine coolant level
- Fuel lines and hoses*2
- Function of all lights
- Brake lines, hoses and connections
- Brake fluid level
- Disc brakes
- Tire inflation pressure and tire wear
- Steering operation and linkages
- Power steering fluid level
- Front and rear suspension, ball joints and wheel bearing axial play
- Driveshaft dust boots
- Washer fluid level

35K Miles (28 months)
Replace engine oil
Replace engine oil filter
Replace air filter
Rotate tires
Lubricate all locks and hinges
Inspect:
- Drive belts
- Engine coolant level
- Function of all lights
- Brake fluid level
- Tire inflation pressure and tire wear
- Power steering fluid level
- Washer fluid level

40K Miles (32 months)
Replace engine oil
Replace engine oil filter
Rotate tires
Lubricate all locks and hinges
Inspect:
- Engine coolant level
- Function of all lights
- Brake fluid level
- Tire inflation pressure and tire wear
- Power steering fluid level
- Washer fluid level

45K Miles (36 months)
Replace engine oil
Replace engine oil filter
Rotate tires
Lubricate all locks and hinges
(Continued)
Inspect:
- Exhaust system and heat shields - Every 45,000 miles or 5 years
- Engine coolant level
- Function of all lights
- Brake fluid level
- Disc brakes
- Tire inflation pressure and tire wear
- Power steering fluid level
- Washer fluid level

50K Miles (40 months)
Replace engine oil
Replace engine oil filter
Rotate tires
Clean air filter
Lubricate all locks and hinges
Inspect:
- Engine coolant level
- Function of all lights
- Brake fluid level
- Tire inflation pressure and tire wear
- Power steering fluid level
- Washer fluid level

55K Miles (44 months)
Replace engine oil
Replace engine oil filter
Rotate tires
Lubricate all locks and hinges
Inspect:
- Engine coolant level
- Function of all lights
- Brake fluid level
- Tire inflation pressure and tire wear
- Power steering fluid level
- Washer fluid level

60K Miles (48 months)
Replace engine oil
Replace engine oil filter
Replace engine coolant (except FL22 type)*
Replace spark plugs!
Replace manual transmission oil
Replace rear differential oil
Rotate tires
Tighten bolts and nuts on chassis and body
Lubricate all locks and hinges
Inspect:
- Engine coolant level
- Fuel lines and hoses*2
- Hoses and tubes for emission*2
- Function of all lights
- Brake lines, hoses and connections
- Brake fluid level
- Disc brakes
- Tire inflation pressure and tire wear
- Steering operation and linkages
- Power steering fluid level
- Front and rear suspension, ball joints and wheel bearing axial play
- Driveshaft dust boots
- Washer fluid level

Additional Operations & Exceptions

Annually
Inspect flat tire repair kit (if installed)*3.

!Spark Plugs
Replace every 60,000 miles.

Engine Valve Clearance
Audible inspect every 75,000 miles, if noisy, adjust.

Engine Coolant
FL22 type*1 - Replace at first 120,000 miles or 10 years; after that, every 60,000 miles or 5 years.

**Except FL22 type - Replace at first 60,000 miles or 4 years; after that, every 2 years.*

**1: Use FL22 type coolant in vehicles with the inscription "FL22" on the radiator cap itself or the surrounding area. Use FL22 when replacing the coolant.*

**2: For emissions footnote see owner's manual.*

**3: Check the tire repair fluid expiration date every year when performing the periodic maintenance. Replace the tire repair fluid bottle with a new one before the expiration date.*

Canada and Puerto Rico residents refer to your owner's manual